

TECHNICAL DATA SHEET

BIOCLEAN 360SC

Super Concentrated Blue Deodorising Detergent for Sanitation of Aircraft Toilet Systems

DESCRIPTION

BIOCLEAN 360SC is a blue coloured super concentrated toilet cleaning fluid, specifically formulated to clean and deodorise aircraft lavatories. A state-of-the-art unique combination of detergents, scale inhibitor and deodorising properties prevents foul odours and keeps aircraft toilets clean and fully operational. This novel chemistry is VOC free and prevents ammonia and formaldehyde generation. BIOCLEAN 360SC can be added as a concentrate into tank trucks and used diluted for the treatment of on-board sanitary facilities. It can also be used to add to on-board reservoirs or waste tank systems. It is suitable for both toilet recirculation and vacuum systems.

Passengers and crew will notice perfect odour control and improved performance from recirculating toilets. Ground handlers will benefit from improved hygiene safety in disposing of waste that has been correctly treated before removal from vacuum waste tanks.



FEATURES & BENEFITS

- **Fast Acting and Long Lasting** - manufactured with powerful ingredients to start working immediately to control odours and reduce deposits in the toilet waste system and continue working throughout the flight.
- **Long-lasting Air Freshener** - slow-release pine scent acts as a long-lasting deodorant and air freshener boosting performance every time the toilet is flushed.
- **Low foaming during flush** - contains a powerful anti-foaming agent to eliminate toilet foaming within 20 seconds.
- **Safe to use** – Will not stain fabrics, rubber, and plastic materials.
- **Biodegradable formulation** – safe for the environment
- **Super Concentrated** – 1:640 high dilution rate reduces chemical usage and environmental impact.
- Recyclable packaging.
- Calculated Carbon Footprint.



APPROVALS AND ACCREDITATIONS

- AMS1476 - BSS7432
- Airbus CML 11GCA1

INSTRUCTIONS D'UTILISATION

BIOCLEAN 360SC is a highly concentrated product : 1 litre for 640 litre of water (~0.3%) for optimal performance depending upon the duration of the flight (see below table). It can be used for vacuum waste tanks or recirculating waste tanks. Pour the product into the toilet water tank. Let product mix with water and create a uniform blue color.

TECHNICAL DATA SHEET

	AIRCRAFT SIZE			
SERVICING INTERVAL	Narrow Bodied B737, A319,320,321	Wide Bodied B767, A330	Wide Bodied B777, 787, A340, 350	Super Jumbo A380
Short haul flights (6 – 12 hours)	30 – 50mL per precharge	50 – 80mL per precharge	50 – 80mL per precharge	80 – 100mL per precharge
Medium haul flights (12 – 24 hours)	50 – 80mL per precharge	80 – 100mL per precharge	80 – 100mL per precharge	100 – 120mL per precharge
Long haul flights (>24 hours)	80 – 100mL per precharge	100 – 120mL per precharge	100 – 120mL per precharge	100 – 120mL per precharge

Contact your Account Manager about a dosing rate specific to your requirements.

PHYSICAL PROPERTIES

Appearance: Clear, dark blue liquid.

Odour: Fresh pine.

Shelf Life: 3 years from date of manufacture.

ORDERING INFORMATION

Product Code	Product	Units /Carton	Weight /carton (kg)	Carton Dimensions (cm)	CO ₂ /units (EXW Paris)
2319/42	Bioclean 360 5L jerrycan	4	21,5	39 x 35 x 28 cm	Coming soon
2319/51	Bioclean 360 20L jerrycan	-	20,5	-	Coming soon
2319/64	Bioclean 360 210L drum	-	212	-	Coming soon
2319/1000	Bioclean 360 1 000L IBC	-	1025	-	Coming soon



**CONTACT US TO KNOW MORE ABOUT CARBON FOOTPRINT
AND CARBON OFFSET FOR NETZEROCO₂ PRODUCTS**



FIRST AID: Never give anything by mouth to an unconscious person. If you feel unwell, seek medical advice immediately (show the label where possible). IF INHALED: Assure fresh air breathing. Allow the victim to rest. IF ON SKIN: Remove affected clothing and wash all exposed skin area with mild soap and water, followed by warm water rinse. IF IN EYES: Rinse immediately with plenty of water. Remove contact lenses, if present and easy to do. Continue rinsing. Obtain medical attention if pain, blinking, or redness persist. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. Obtain emergency medical attention.

STORAGE: BIOCLEAR 360SC can be stored in a cool, dry, well-ventilated area.

DISPOSAL: Dispose of content and packaging in accordance with local/national regulations. Avoid release to the environment.

WARRANTY – All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, expressed or implied, for which seller assumes legal responsibility and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent. Created 28 November 2022. Modified 10th October. Date Printed 29/10/2024 1:30 PM